


REVERSE RETURN CONFIGURATION



Start / Stop Function
 24V Relays at Each Heat
 Pump to Open and Close Dry
 Contact on the VFD Terminals
 *** VFD Terminals-(S1-SC)
 Normally Closed Contact***

